

MULTIPURPOSE 7 DAYS DIGITAL PROGRAMMABLE TIMER




TM-619- SERIES

GENERAL INFORMATION

This 7 DAY's Digital Timer Series is available in 230VAC, with voltage free output (5PIN) or voltage output (4PIN).

The Timer Program & Clock Memory is retained by Replaceable CR2032 or Rechargeable V80H Lithium ION Battery.

This Timer Series is accurate to the minute with either 8 or 18 ON/OFF Events per day



The 15 combination of Daily-Programs, leads to great convince to user to choose desired Days of Week

| | | | | | | | |
|-----|----|----|----|----|----|----|----|
| 1. | MO | TU | WE | TH | FR | SA | SU |
| 2. | MO | | | | | | |
| 3. | | TU | | | | | |
| 4. | | | WE | | | | |
| 5. | | | | TH | | | |
| 6. | | | | | FR | | |
| 7. | | | | | | SA | |
| 8. | | | | | | | SU |
| 9. | MO | TU | WE | TH | FR | | |
| 10. | | | | | | SA | SU |
| 11. | MO | TU | WE | TH | FR | SA | |
| 12. | MO | TU | WE | | | | |
| 13. | | | | TH | FR | SA | |
| 14. | MO | | WE | | FR | | |
| 15. | | TU | | TH | | SA | |

The 7 days 24hrs programable timer switch can automatically switch on and switch off various kind of equipments at **preset time**

It's widely used in 7 day programing of streetlight, neon lights, lamps, water heaters, air conditions, billboards, signboards, sprayers, agriculture or aquarium equipments, etc.

DESCRIPTION MODELS TYPES

20AMP@250VAC TM619H-2 4P

20AMP@250VAC TM619H-2 5P

These are available with replaceable battery CR2032

16AMP@250VAC TM619H-2 4P

These are available with rechargeable battery V80H

PROGRAMMING THE TIMER #1

A. Functional description of the Button on Panel

- TIMER:** Programing Mode
- MANUAL:**
 - Select "ON, AUTO, OFF"
 - "Cancel Reset Program"
- CLOCK:**
 - Clock settings "Day, Hour, Minutes"
 - Press & Hold for AM/PM
- DAY:** adjust the day of the week
- HOUR:** adjust the hour
- MIN:** adjust the minutes
- LED:** Indicates ON / OFF status
- RESET:** Reset the Timer setting

B. Adjusting the CLOCK

- Press and hold the "CLOCK" and the press "DAY" key, "HOUR" key, "MIN" key respectively to adjust the clock of timer to accurate DAY, HOUR, MINUTE.
- Press and hold the "CLOCK" key over 3 Sec for "AM&PM"

LCD Screen shall display 00:00 - 23:59 in 24Hour Format.

C. Start to programming the TIMER

1. Press **TIMER** key. LCD screen shall show **1-ON** __: __
2. Press **DAY** key to select any of the 15 combinations of daily programs. Every press of **DAY** key, LCD shall alternate through the 15 combinations.
3. Press **HOUR, MIN** respectively to set the desired Hour and Minutes for **1-ON**
4. Press **TIMER** key again, the LCD screen shall show **1-OFF** __: __
5. Press **DAY** key to select any of the 15 combinations of daily programs. Every press of **DAY** key, LCD shall alternate through the 15 combinations.

Day-Combination should be same for ON & OFF

6. Repeat Step 3 to set desired Hour and Minutes for **1-OFF**
7. Press **TIMER** key again, the LCD screen shall show **2-ON** __: __
8. Repeat Programming Step 2, 3 & 4 to set the ON / OFF program-periods (Events)
1-ON __: __ => **1-OFF** __: __ => ● ● ● ● **18-OFF** __: __
9. When finished program-setting (events) press **CLOCK**. Press Clock after the number of events but ensure its pressed after setting the OFF Time.

D. To Review or Reset the Programs

Press "**TIMER**" key, on each press the LCD will display 18-ON and 18-OFF events. If you want to change any of the event timer, press **MANUAL** key and the follow step 2 & 3.

Electrical Installation should only be carried out by a competent person (someone who has the necessary skills, knowledge and experience to carry out the work safely).

PROGRAMMING THE TIMER #2

E. COUNT DOWN FUNCTION:

In clock mode, Press **CLOCK** and **TIMER** together over 3 Sec for **Count down Function of Timer**, LCD screen shall display **d 00:00**

Press and hold **CLOCK** key and **HOUR, MIN** key respectively to set the count down time (0:00 to 23:59)

Press the **MANUAL** key to start the countdown. The Timer will **ON and OFF after the set period**. Press **TIMER** to STOP the countdown.

F. AUTO TIME DEFLECTION Correction Weekly.

In Clock mode, press **MANUAL** and **TIMER** key into auto time deflection correction mode **7 d 00:00**

Press **DAY** key to adjust time deflection, the setting range is +/- 30 Sec. Every week the timer will adjust the time by the set sec.

The drift in the time over a week needs to be observed with an accurate clock, to know the drift.

G. SLEEP MODE

In the clock mode, Press **DAY, HOUR** keys over 3 sec the timer will go to sleep mode and display is shutdown. This feature to be used when the timer is not used for a long timer and the battery CR2032 life is extended. To activate Reset the timer, Press **ⓧ** key.

